

3	Aliph	Apex	Apple	Audiovox
Bang & Olufsen	Belkin	BenQ	Blackberry	BlueAnt
Brand	Cowon	Creative	Dash	Dell
Disney	Dopod	E-Plus	Eten	Garmin
Gigabyte	Grundig	Helio	HP	HTC
i-mate	Insignia	Iogear	Iqua	iRiver
Jabra	Jens of Sweden	Kodak	Krome	Kyocera
LG	Logitech	Memorex	Microsoft	Motorola
Netgear	Nintendo	Nokia	O2	Palm
Pharos	Philips	Plantronics	Qtek	Qualcomm
RCA	Rio	Samsung	Sandisk	Sanyo
Sharp	Sidekick	Siemens	SoftBank	Sony
Sony Ericsson	TomTom	Toshiba	UBiQUIO	Voice Star
VuGo	Wi-Gear	ZTE		

Extra connectors*:

Mini USB	Motorola Narrow	Motorola Wide	Nintendo DS
Nintendo DS Lite	PSP	Samsung A1	Samsung A2

**extra connectors are not included and must be purchased separately.*

3

Skypephone s1 / Skypephone s2

Aliph

Jawbone

Apex

Apple

iPhone / iPod / iPod Classic / iPod Mini / iPod Nano / iPod Photo / iPod Touch / iPod Video

Audiovox

CDM8400 / CDM8410 / CDM8450 / CDM8455 / CDM8610VM / CDM8615 / CDM8615CS / CDM8900 / CDM8910 / CDM8910BM / CDM8910VM / CDM8910VW / CDM8912 / CDM8915 / CDM8930 / CDM8940 / CDM8940VW /

CDM9200 / CDM9900 / CDM9950 / CDM9950SP / Mogul / PM8912 / PM8920 / PM8920 / PPC-6700 / PPC-6800 / SMT 5600 / V1600

Bang & Olufsen

EarSet 2

Belkin

Skype WiFi F19900GN-SK / WiFi Phone

BenQ

EU hhb 505 / EU hhb 515 / EU hhb 535 / EU hhb 600

Blackberry

5790 / 5810 / 5820 / 6210 / 6220 / 6230 / 6280 / 6510 / 7100g / 7100i / 7100r / 7100t / 7100v / 7100x / 7105t / 7130c / 7130e / 7130g / 7130v / 7210 / 7230 / 7250 / 7280 / 7290 / 7510 / 7520 / 8700c / 8700g / 8700r / 8700v / 8703e / 8705g / 8707g / 8707h / 8707v / 8800 / 8800g / 8820 / 8830 / 8830 World Edition / Bold 9000 / Curve 8300 / Curve 8310 / Curve 8320 / Curve 8330 / Curve 8900 / Pearl 8100 / Pearl 8110 / Pearl 8120 / Pearl 8130 / Pearl 8220 / Storm 9500 / Storm 9530

BlueAnt

Supertooth II / Supertooth III / X3 Micro / Z9

Brand

Cowon

A2 / D2 / D2 2GB / D2 4GB / iAudio A2 / M3 20Gb / M3 40Gb / M3L 20Gb / X5

Creative

MuVo Slim / MuVo Slim XMOD / Zen / Zen Micro / Zen MicroPhoto / Zen Mozaic / Zen Nano Plus / Zen Neon / Zen Neon 2 / Zen Sleek / Zen Sleek Photo / Zen Stone / Zen Stone with speaker / Zen Stone Plus / Zen Stone Plus with built-in speaker / Zen V / Zen V Plus / Zen Wav / Zen X-Fi / Zen X-Fi with WLAN

Dash

Dash / Dash Express

Dell

Axim X3 / Axim X30 / Axim X3i / Axim X50 / Axim X50v / Axim X51 / Axim X51v / Pocket DJ

Disney

Mix Max 19012 / Mix Max DS19005

Dopod

565 / 566 / 575 / 577W / 585 / 586W / 595 / 696i / 699 / 818 / 818 Pro / 828 / 838 / 838 Pro / 900 / C500 / C720W / C730 / C800 / CHT 9000 / D810 / M700 / P100 / P800W / S900 / U1000

E-Plus

PDA IV

Eten

Glofiish DX900 / Glofiish G500 / Glofiish G500+ / Glofiish M500 / Glofiish M550 / Glofiish M600 / Glofiish M600+ / Glofiish M700 / Glofiish M750 / Glofiish M800 / Glofiish M810 / Glofiish V900 / Glofiish X500 / Glofiish X500+ / Glofiish X600 / Glofiish X610 / Glofiish X650 / Glofiish X800 / Glofiish X900

Garmin

Edge 205 / Edge 305 / Edge 605 / Edge 705 / Forerunner 203 / Forerunner 205 / Forerunner 301 / Forerunner 305 / iQue 3200 / iQue 3600 / Nuvi 200 / Nuvi 200w / Nuvi 205 / Nuvi 205w / Nuvi 205wt / Nuvi 215t / Nuvi 250 / Nuvi 250w / Nuvi 255 / Nuvi 255t / Nuvi 255w / Nuvi 255wt / Nuvi 260 / Nuvi 260w / Nuvi 265t / Nuvi 265wt / Nuvi 270 / Nuvi 275t / Nuvi 300 / Nuvi 300t / Nuvi 310 / Nuvi 310t / Nuvi 350 / Nuvi 360 / Nuvi 370 / Nuvi 500 / Nuvi 510 / Nuvi 550 / Nuvi 650 / Nuvi 660 / Nuvi 670 / Nuvi 680 / Nuvi 750 / Nuvi 760 / Nuvi 760t / Nuvi 765 / Nuvi 765t / Nuvi 770 / Nuvi 775t / Nuvi 785t / Nuvi 860 / Quest / StreetPilot C310 / StreetPilot C330 / StreetPilot C340 / StreetPilot C510 / StreetPilot C530 / StreetPilot C550 / StreetPilot C580 / StreetPilot i2 / StreetPilot i3 / StreetPilot i5 / Zumo 400 / Zumo 450 / Zumo 500 / Zumo 550

Gigabyte

GSmart i120 / GSmart i300 / GSmart MS800 / GSmart MS820 / GSmart MW700 / GSmart MW998 / GSmart Q60 / GSmart T600

Grundig

GR980

Helio

Kickflip

HP

iPAQ 100 / iPAQ 110 / iPAQ 111 Classic Handheld / iPAQ 200 / iPAQ 210 / iPAQ 211 Enterprise Handheld / iPAQ 300 / iPAQ 310 Travel Companion / iPAQ 500 / iPAQ 510 / iPAQ 510 Voice Messenger / iPAQ 512 / iPAQ 514 / iPAQ 514 Messenger / iPAQ 600 / iPAQ 610 / iPAQ 610c / iPAQ 612 / iPAQ 612c / iPAQ 614 / iPAQ 910 Business Messenger / iPAQ 910c / iPAQ Data Messenger / iPAQ HW6800 / iPAQ RW6800 / iPAQ RW6815 / iPAQ RW6818 / iPAQ RW6828 / iPAQ RW6828 Titanium Black / iPAQ RX4000 / iPAQ RX4200 / iPAQ RX4240 / iPAQ RX4550 / iPAQ RX5700 / iPAQ RX5710 / iPAQ RX5720 / iPAQ RX5725 / iPAQ RX5730 / iPAQ RX5765 / iPAQ RX5770 / iPAQ RX5775 / iPAQ RX5780 / iPAQ RX5900 / iPAQ RX5910 / iPAQ RX5915 / iPAQ RX5935 / iPAQ RX5940 / iPAQ RX5965 / iPAQ RX5970 / iPAQ Travel Companion / XV6700

HTC

2125 / 5600 / 5800 / 6700Q / 8100 / 8125 / 8310 / 8525 / 8925 / Advantage / Advantage EU / Advantage II / Advantage US / Amadeus / Ameo / Apache / Artemis / Athena / Athena 100 / Breeze / C730 / Cavalier / Charmer / Dash / Dream / Elf / Excalibur / Faraday / Feeler / Fusion / G1 Android Google Phone / Galaxy / Herald / Herm 300 / Hermes / Hermes 100 / Hermes 200 / Hermes 300 / Himalaya / Hurricane / Iris / Juno / Kaiser / Libra / Libra 100 / Love / M650 / M700 / Magic / Magician / MDA Compact III / MDA Pro / MDA Vario / MDA Vario II / MDA Vario IV / Mogul / MTeoR / Muse / Nike 100 / Oxygen / P3050 / P3300 / P3350 / P3400 / P3452 / P3470 / P3600 / P3600i / P3650 / P3700 / P3701 / P3702 / P4000 / P4300 / P4350 / P4550 / P5500 / P5520 / P5530 / P5550 / P6300 / P6500 / Panda / Pharos / PPC 6700 / PPC 6800 / Prophet / Robbie / S310 / S620 / S620C / S621 / S630 / S640 / S710 / S720 / S730 / S740 / SDA / SDA Music / SDA Music 2 / Sedna / Shadow / SP5m / SPV C100 / SPV C500 / SPV C550 / SPV C600 / SPV C700 / SPV E650 / SPV M3000 / SPV M3100 / SPV M500 / SPV M5000 / SPV M600 / Tilt 8925 / Titan / Tornado / Touch / Touch 3G / Touch Cruise / Touch Cruise Premium / Touch Diamond / Touch Dual / Touch Find / Touch HD / Touch P3450 / Touch Pro / Touch Slide / Touch Viva / Trinity / Trinity 100 / Typhoon / TyTN / TyTN II / Universal / V1240 / V1605 / V1640 / Vogue / Vogue 100 / Vox / VPA Compact / VPA IV / Wallaby / Wing / Wizard / X7500 / X7501 / X7510 / XV6700 / XV6800 / XV6900

i-mate

Jam / Jam Black / JAMA / JAMA 101 / JAMA 201 / JAMin / JAQ / JAQ3 / JAQ4 / JasJam / JasJar / K-Jam / New Jam / PDAL / SmartFlip / SP JAS / SP3 / SP3i / SP4m / SP5 / SP5m / SPL / Ultimate 5150 / Ultimate 6150 / Ultimate 7150 / Ultimate 8150 / Ultimate 8502 / Ultimate 9150 / Ultimate 9502

Insignia

Amigo / NS-2V17 / NS-2V17b / NS-2V17r / NS-4V17 / NS-4V17b / NS-4V17r / NS-4V24 / NS-8V24 / NS-DA1G-Sport / NS-DA2G-Sport / NS-DV2G / NS-DV4G / NS-DVB4G / Sport 1GB / Sport 2GB

logear

GBE211 / GBHFK201W6 / GBMH201 / GBMHKIT / GBMHPODKIT

Iqua

603 Sun / BHS-303 / BHS-312 / BHS-601 / BHS-701 / BHS-801 / BHS-802 / BHS-808 / PHF-602 / Vizor / Vizor Sun

iRiver

B20 / Clix 2nd Generation 2GB / Clix 2nd Generation 4GB / Clix 2nd Generation 8GB / Clix 2nd Generation U20 / H100 / H120 / H140 / H300 / iFP-1000 / iFP-300 / iFP-590T / iFP-595T / iFP-599T / iFP-700 / iFP-800 / iFP-900 / PMC-100 / T10 / T30 / T50 / T60 / X20

Jabra

A125s / BT2010 / BT2020 / BT3030 / BT4010 / BT530 / BT620s / BT8040 / JX20

Jens of Sweden

MP-400 / MP-450 / MP-X / MP-X

Kodak

Krome

iQ700 / Navigator F1 / Spy

Kyocera

1135 / 1155 / 2119 / 2119b / 2135 / 2235 / 2255 / 2300 / 2325 / 2345 / 3200 / 3225 / 3245 / 3250 / 7135 / Blade / E2000 / Flasher V7 / K10 / K10 Royale / K110 / K112 / K4130 / K433 / K433C / K433L / K434 / K434N / K440 / K444 / K454 / K454L / K454LC / K454N / K454NC / K480 / K493LC / K494 / K494LC / K494NC / K494XLC / K7 / K7 Rave / K9 / K9 Rave / KE413 / KE413c / KE414 / KE414c / KE423 / KE423C / KE424 / KE424c / KE433 / KE433c / KE434 / KE434C / Koi / KWC-2135 / KWC-2235 / KX1 / KX1i / KX1v / KX2 / KX413 / KX414 / KX424 / KX433 / KX434 / KX440 / KX444 / KX9 / KX9A / KX9B / KX9C / KX9D / KX9E / LIngo / M1000 / Mako / Milan / Oyst / Phantom / QCP2027 / QCP2035 / QCP2035A / Rave / Royale / S2400 / S4000 / SoHo / Tempo / TNT / Wild Card

LG

1200 / 3600 / AX155 / AX260 / AX275 / AX300 / AX380 / AX500 / AX565 / AX585 / AX830 / AX8600 / C810 / CB630 / CE110 / CG180 / Chocolate / Chocolate 3 / Chocolate Platinum / Chocolate-Cherry / Chocolate-Green / Chocolate-Mint / Chocolate-Pink / Chocolate-Red / Chocolate-White / Cookie / CU515 / CU515 Black / CU515 Plum / CU575 / CU720 / CU915 / CU920 / Dare / Decoy / EnV / EnV Green / EnV Orange / enV2 / Flare / GC900 / GD900 / Glimmer / GM730 / HB620T / HBM-300 / HBM-500 / HBM-510 / HBM-550 / HBM-560 / HBM-710 / HBM-730 / HBM-750 / HBM-755 / HBM-760 / HBM-761 / HBM-770 / HBS-110 / HBS-150 / HBS-200 / HBS-250 / Hero / Invision / KB770 / KC550 / KC780 / KC910 / KE260 / KE500 / KE590 / KE770 / KE800 / KE820 / KE830 / KE850 / KE970 / KEYBO 9100 / KF240 / KF300 / KF310 / KF350 / KF390 / KF510 / KF600 / KF700 / KF700Q / KF710 / KF750 / KF755 / KF900 / KG195 / KG270 / KG275 / KG280 / KG288 / KG320 / KG320s / KG328 / KG330 / KG375 / KG77 / KG800 / KG808 / KG810 / KG820 / KG830 / KG890 / KG90 / KG900 / KG90c / KG98 / KG99 / KM330 / KM338 / KM380 / KM386 / KM500 / KM710 / KM900 / KP100 / KP105 / KP110 / KP130 / KP199 / KP210 / KP215 / KP220 / KP235 / KP260 / KP265 / KP320 / KP500 / KS10 / KS20 / KS360 / KS500 / KT250 / KT520 / KT610 / KT770 / KU250 / KU311 / KU380 / KU385 / KU580 / KU800 / KU811 / KU830 / KU950 / KU970 / KU990 / KU990R / KX166 / L600v / LG600 / LG830 / Lotus / LX1200 / LX150 / LX160 / LX165 / LX260 / LX400 Blue / LX400 Burgundy / LX570 / LX600 / M540 / M7600 Beat DJ / MG295 / MG800 / MG800C / MG810C / MG810D / MSB-100 / Muziq Black / Muziq Pink / MX800 / Orsay / PRADA / Prada II / Renoir / Reveal / Rhythm / Rumor / S7220 / S7220 Ultra b / S7350 Ultra s / Scoop / Secret / Shine / Slyde / Spyder / Swift / TG800 / TM510 / Trax / TU515 / TU575 / TU720 / U250c / U310 / U830 / U960 / U970 / U990 / UX260 / UX300 / UX380 / UX565 / UX585 / UX830 / Vantage 830 / Venus / V1125 / Viewty / Virgo / Voyager / Vu / Vu TV / VX10000 / VX10K / VX5300s / VX5400 / VX5500 / VX8350 / VX8350 Red / VX8360 / VX8500 / VX8550 / VX8550 Black / VX8550 Dark Blue / VX8550 Dark Red / VX8550 Ice Blue / VX8560 / VX8600 / VX8600 Red / VX8600 Silver / VX8610 / VX8700 / VX8800 / VX9100 / VX9400 / VX9700 / VX9900 / WAVE / WIne 280

Logitech

Mobile Express 980

Memorex

MMP8564A / MMP8565 1GB / MMP8567 / MMP8575 2GB / MMP8585 / MMP8620 / MMP8640

Microsoft

Zune

Motorola

A668 / A70 / A732 / A780 / A810 / A910 / Adventure V750 / Aura / Blend / C290 / C305 / C331g / C332 / C333 / C362 / C363 / E1070 / E610 / E615 / E680 / E680i / E685 / E770 / E770v / EM35 / G520 / H3 / H350 / H375 / H385 / H500 / H550 / H555 / H605 / H670 / H680 / H681 / H685 / H700 / H710 / H721 / H800 / H9 / HS830 / HT820 / i290 / i425 / i500 / i550 / i576 / i700 / i776 / i876 / ic402 / ic502 / ic602 / ic902 / ic902 Deluxe / IHF1000 / Krave ZN4 / KRZR K1 / KRZR K1m / KRZR K3 / KRZR MAXX K3 / L2 / L6 / L6i / M300 / M500 / M710 Permanent Mount Phone / M800 Permanent Mount Phone / M930 Permanent Mount Phone / M990 Smart Rider / Ming A1200 / Ming A1200e / MING A1600 / MING A1800 / MOTO EM25 / MOTO EM30 / MOTO i335 / MOTO Q / MOTO Q 11 / MOTO Q 8 / MOTO Q 9c / MOTO Q 9c Lime / MOTO Q 9e / MOTO Q 9h / MOTO Q 9m / MOTO Q global / MOTO Q gsm / MOTO Q music 9m / MOTO VU204 / MOTO Z10 / MOTO Z6c world edition / MOTO Z9 / MOTO ZN200 / MOTOACTV W450 / MOTOFOFONE F3 / MOTONAV TN20 / MOTOPURE H12 / MOTORAZR2 V8 / MOTORAZR2 V8 Luxury Edition / MOTORAZR2 V9 / MOTORAZR2 V9m / MOTORAZR2 V9x / MOTOROKR E8 / MOTOROKR S9 / MOTOROKR U9 / MOTOROKR W5 / MOTOZINE ZN5 / PEBL / PEBL E6 / PEBL U6 / Rapture VU30 / RAZR H3 / RAZR MAXX V3 / RAZR MAXX V6 / RAZR MAXX V6 Ferrari / RAZR MAXX Ve / RAZR V3 / RAZR V3 Black / RAZR V3 Red / RAZR V3a / RAZR V3c / RAZR V3e / RAZR V3i / RAZR V3i Chrome White / RAZR V3i DG / RAZR V3im / RAZR V3m / RAZR V3m Red / RAZR V3r / RAZR V3t / RAZR V3x / RAZR V3xx / RAZR V6 maxx / RAZR VE20 / RAZR VE75 / RAZR2 U9 / RAZRWIRE / Renegade V950 / RIZR Z3 / RIZR Z6 / RIZR Z6c / RIZR Z6cx World Edition / RIZR Z6tv / RIZR Z6tv / RIZR Z8 / ROKR E2 / ROKR E6 / ROKR E8 / ROKR Z6 / ROKR Z6m / ROKR Z6w / S805 / Sidekick Slide / SLVR / SLVR i-mode / SLVR L6 / SLVR L7 / SLVR L72 / SLVR L7c / SLVR L7e / SLVR L7i / SLVR L9 / SLVR V8 / SLVR Z10 / T305 / T505 / T605 / The Buzz / V190 / V191 / V195 / V197 / V235 / V320 / V323 / V323i / V325 / V325i / V360 / V360v / V361 / V365 / V6 / V660 / VE538 / W175 / W177 / W180 / W220 / W230 / W231 / W270 / W315 / W320a / W355 / W360 / W362 / W370 / W372 / W375 / W377 / W385 / W388 / W395 / W396 / W490 / W510 / W755 / Z Slider / Z6c World Edition / Z8

Netgear

Nintendo

Nokia

1100 / 1101 / 1108 / 1110 / 1110i / 1112 / 1200 / 1208 / 1209 / 1221 / 1255 / 1260 / 1261 / 1265 / 1325 / 1508 / 1508i / 1600 / 1606 / 1650 / 1661 / 1680 Classic / 2100 / 2110 / 2112 / 2115i / 2116 / 2116i / 2118 / 2125 / 2125i / 2126 / 2126i / 2128 / 2128i / 2135 / 2255 / 2260 / 2270 / 2275 / 2280 / 2285 / 2300 / 2310 / 2323 Classic / 2330 Classic / 2505 / 252 / 252CC / 252N / 252NC / 2600 / 2600 Classic / 2610 / 2626 / 2630 / 2650 / 2651 / 2652 / 2660 / 2680 Slide / 2760 / 282 / 2855 / 2865 / 2865i / 3100 / 3105 / 3108 / 3109 / 3109 Classic / 3110 / 3110 Classic / 3110 Evolve / 3120 / 3120 Classic / 3125 / 3128 / 3152 / 3155 / 3155i / 3200 / 3205 / 3210 / 3220 / 3230 / 3250 XpressMusic / 3285 / 3300 / 3310 / 3315 / 3330 / 3350 / 3360 / 3361 / 3385 / 3390 / 3395 / 3410 / 3500 / 3500 Classic / 3510 / 3510i / 3520 / 3530 / 3555 / 3560 / 3570 / 3585 / 3585i / 3586 / 3586i / 3587i / 3588i / 3589i / 3590 / 3595 / 3600 / 3600 Slide / 3610 / 3610 Fold / 3620 / 3650 / 3660 / 5000 / 5070 / 5100 / 5110 / 5120 / 5125 / 5130 / 5130 XpressMusic / 5140 / 5140i / 5160 / 5160i / 5165 / 5165i / 5170 / 5170i / 5180 / 5180i / 5185 / 5185i / 5190 / 5200 / 5210 / 5220 XpressMusic / 5300 Classic / 5300 XpressMusic / 5310 XpressMusic / 5320 XpressMusic / 5500 Sport / 5510 / 5610 XpressMusic / 5630 XpressMusic / 5700 XpressMusic / 5800 Xpress Music / 5800 Xpress Music North American Version / 6010 / 6011i / 6015 / 6015i / 6016i / 6019i / 6020 / 6021 / 6030 / 6060 / 6061 / 6062 / 6070 / 6080 / 6085 / 6086 / 6088 / 6100 / 6101 / 6101 Classic / 6102 / 6102i / 6103 / 6103b / 6108 / 6110 / 6110 Navigator / 6111 / 6115i / 6120 / 6120 Classic / 6120i / 6121 / 6121 Classic / 6124 / 6125 / 6126 / 6130 / 6131 / 6131 NFC / 6133 / 6136 / 6150 / 6151 / 6152 / 6155 / 6155i / 6160 / 6160i / 6161 / 6161 Flip / 6161i / 6162 / 6162 Flip / 6162i / 6165i / 6168 / 6170 / 6180 / 6185 / 6185i / 6190 / 6200 / 6205 / 6210 / 6210 Navigator / 6212 Classic / 6220 / 6220 Classic / 6225 / 6230 / 6230i / 6233 / 6234 / 6235 / 6235i / 6236i / 6250 / 6255 / 6255i / 6256i / 6260 / 6260 Slide / 6263 / 6265 / 6265i / 6267 / 6268 / 6270 / 6275i / 6280 / 6282 / 6288 / 6290 / 6300 / 6300i / 6301 / 6310 / 6310i / 6340 / 6340i / 6360 / 6370 / 6385 / 640 / 650 / 6500 / 6500 Classic / 6500 Slide / 6500c / 6510 / 6555 / 6560 / 6585 / 6590 / 6590i / 6600 / 6600 Fold / 6600 Slide / 6610 / 6610i / 6620 / 6630 / 6650 / 6651 / 6670 / 6680 / 6681 / 6682 / 6708 / 6800 / 6810 / 6820 / 6820i / 6822 / 7070 Prism / 7088 / 7100 / 7100 Supernova / 7110 / 7160 / 7190 / 7200 / 7210 / 7210 Supernova / 7250 / 7250i / 7260 / 7270 / 7280 / 7310 Supernova / 7360 / 7370 / 7372 / 7373 / 7380 / 7390 / 7500 Prism / 7510 Supernova / 7600 / 7610 / 7610 Supernova / 7650 / 770 / 7700 / 7710 / 7900 Crystal Prism / 7900 Prism / 8110 / 8210 / 8250 / 8260 / 8265 / 8265i / 8270 / 8280 / 8290 / 8310 / 8390 / 8600 Luna / 8800 / 8800 Arte / 8800 Carbon Arte / 8800 Gold Arte / 8800 Sapphire Arte / 8800 Sirocco Edition / 8801 / 8810 / 8850 / 8850 Gold / 8855 / 8860 / 8890 / 8910 / 8910i / 9000 Communicator / 9110 Communicator / 9110i Communicator / 9200 / 9210 Communicator / 9210i Communicator / 9290 / 9300 / 9300i / 9500 / BH-100 / BH-101 / BH-102 / BH-103 / BH-200 / BH-201 / BH-202 / BH-203 / BH-204 / BH-205 / BH-206 / BH-207 / BH-208 / BH-210 / BH-211 / BH-212 / BH-213 / BH-300 / BH-301 / BH-301-LT / BH-302 / BH-303 / BH-304 / BH-500 / BH-501 / BH-503 / BH-600 / BH-601 / BH-602 / BH-604 / BH-700 / BH-700-BK / BH-700-WH / BH-701 / BH-702 / BH-703 / BH-800 / BH-800-BK / BH-800-WH / BH-801 / BH-803 / BH-900 / BH-902 / BH-903 / E50 / E51 / E51 Camera Free / E55 / E60 / E61 / E61i / E62 / E63 / E65 / E66 / E70 / E71 / E71 White / E72 / E75 / E90 Communicator / HDW-3 / HS-11W / HS-12W / HS-13W / HS-21W / HS-26W / HS-3W / HS-4W / HS-53W / HS-54W / HS-55W / HS-56W / LD-1W / N-Gage / N-Gage QD / N70 / N70 Music Edition / N71 / N72 / N73 / N73 Music Edition / N75 / N76 / N77 / N770 / N78 / N79 / N80 / N80 Internet Edition / N800 Internet Tablet / N80ie / N81 / N81 8GB / N810 Internet Tablet / N810 WiMax Edition / N82 / N85 / N86 / N90 / N91 / N91 8GB / N92 / N93 / N93i / N95 / N95 8GB / N96 / N97 / PCS 5120 / Shorty / SU-27W / THR850 / THR880 / Tube

O2

Cocoon / Ice / Jet / X1b / X2i / X7 / XDA / XDA Argon / XDA Atmos / XDA Atom / XDA Atom Pure / XDA Comet / XDA Cosmo / XDA Exec / XDA Flame / XDA Graphite / XDA Ignito / XDA II Mini / XDA IQ / XDA Mantle / XDA Mini / XDA Mini Pro / XDA Mini S / XDA Neo / XDA Nova / XDA Orbit / XDA Orbit 2 / XDA Orion / XDA Phone / XDA SP / XDA Star / XDA Stealth / XDA Stellar / XDA Terra / XDA Trion / XDA Zest / XDA Zinc / Xphone II / Xphone II m

Palm

Centro / Centro 686 / Centro 690 / Gandolf / LifeDrive / Treo 500 / Treo 500V / Treo 650 / Treo 650 Headset / Treo 680 / Treo 700p / Treo 700w / Treo 700wx / Treo 750 / Treo 750v / Treo 755p / Treo 800 / Treo 800p / Treo 800w / Treo Pro / Tungsten E / Tungsten E2 / Tungsten T5 / TX / Z22 / Zire 31 / Zire 72 / Zire 72s

Pharos

505 / 525 / 525E / 525P / PGS Phone 600 / PTL 600

Philips

GoGear SA3104-37 / GoGear SA3105-37 / GoGear SA3114-37 / GoGear SA3115-37 / GoGear SA3124-37 / GoGear SA3125-37 / GoGear SA6014-37 / GoGear SA6015-37 / GoGear SA6044-37 / GoGear SA6045-37 / GoGear SA6046-37 / GoGear SA6065-37 / GoGear SA6066-37 / GoGear SA6085-37 / GoGear SA6086-37 / GoGear SA6087-37 / GoGear SA6125-37 / GoGear SA6145-37 / GoGear SA6185-37

Plantronics

Discovery 925 / Explorer 220 / Explorer 230 / Explorer 360 / Explorer 370 / Pulsar 260 / Voyager 815 / Voyager

Otek

1020 / 4040 / 7070 / 8010 / 8020 / 8060 / 8080 / 8100 / 8200 / 8300 / 8310 / 8500 / 8600 / 9000 / 9100 / 9600 / G100 / S100 / S110 / S200 / S300

Qualcomm

QCP2027 / QCP2035 / QCP2035A

RCA

Lyra Jukebox RD2762

Rio

Carbon / ce2100 / Eigen / Karma / Nitrus

Samsung

4930 / A580 / A640 / A990 / Access / Ace / Alias / Beat / Beat b / Beat S / Behold / Black Carbon / Black Jack / Black Jack II / Blast / Bresson / Cricket / DeVe / DM-S105 / Drift / Duos / Emporio Armani / Epix / Eternity / Fin / FlipShot / Giorgio Armani / Gleam / Glyde / Gravity / Heat / Highnote / Hue / i8910 / Impact B / INNOV8 / Instinct / Jayhawk / JetSet / Juke / K3 / K5JQ / Katalyst / Lily / Lime / Luxe / M500 / Memoir / Messenger / miCoach / MM-A700 / MM-A800 / MM-A820 / MM-A920 / MM-A940 / Muse / Musical SGH-F408 / Musical SGH-i458B / MyShot / Mysto / NeXus 25 YP-X5X / NeXus 50 YP-X5Z / Nimbus / Omnia / Omnia HD / P2 / Pixon / PM-A740 / PM-A840 / PM-A880 / Propel / Qbowl / Rant / RL-A760 / Rugby / S2 / S3 / S5 / S5600 / S8300 Ultra Touch / SBH500 / SCH-A565 / SCH-A603 / SCH-i910 / SCH-M490 / SCH-R200 / SCH-R210 / SCH-R300 / SCH-R400 / SCH-R410 / SCH-R430 / SCH-R450 / SCH-R500 / SCH-R510 / SCH-R550 / SCH-R610 / SCH-R800 / SCH-U340 / SCH-U420 / SCH-U470 / SCH-U700 / SCH-U706 / SCH-U740 / SCH-U800 / SCH-U900 / SCH-U908 / SCH-U940 / SCH-V940 / SCH-W460 / SGH-A117 / SGH-A127 / SGH-A226 / SGH-A227 / SGH-A237 / SGH-A436 / SGH-A437 / SGH-A503 / SGH-A516 / SGH-A517 / SGH-A637 / SGH-A706 / SGH-A707 / SGH-A717 / SGH-A727 / SGH-A736 / SGH-A737 / SGH-A746 / SGH-A747 / SGH-A747 / SGH-A767 / SGH-A770 / SGH-A777 / SGH-A827 / SGH-A837 / SGH-A867 / SGH-A930 / SGH-B100 / SGH-B110 / SGH-B130 / SGH-B200 / SGH-B210 / SGH-B2700 / SGH-B300 / SGH-B320 / SGH-B510 / SGH-C140 / SGH-C170 / SGH-C180 / SGH-C250 / SGH-C450 / SGH-C510 / SGH-C520 / SGH-D520 / SGH-D528 / SGH-D780 / SGH-D800 / SGH-D806 / SGH-D807 / SGH-D808 / SGH-D820 / SGH-D828 / SGH-D830 / SGH-D838 / SGH-D840 / SGH-D848 / SGH-D870 / SGH-D880 / SGH-D888 / SGH-D900 / SGH-D900i / SGH-D908 / SGH-D908i / SGH-D980 / SGH-D988 / SGH-E1110 / SGH-E200 / SGH-E200 / SGH-E210 / SGH-E215 / SGH-E230 / SGH-E250 / SGH-E258 / SGH-E390 / SGH-E420 / SGH-E428 / SGH-E500 / SGH-E540 / SGH-E550 / SGH-E570 / SGH-E590 / SGH-E740 / SGH-E768 / SGH-E780 / SGH-E788 / SGH-E790 / SGH-E807 / SGH-E830 / SGH-E840 / SGH-E848 / SGH-E870 / SGH-E878 / SGH-E880 / SGH-E898 / SGH-E900 / SGH-E906 / SGH-E908 / SGH-E950 / SGH-E989 / SGH-F110 / SGH-F200 / SGH-F210 / SGH-F218 / SGH-F250 / SGH-F258 / SGH-F268 / SGH-F270 / SGH-F300 / SGH-F308 / SGH-F330 / SGH-F338 / SGH-F400 / SGH-F480 / SGH-F488 / SGH-F490 / SGH-F498 / SGH-F500 / SGH-F508 / SGH-F700 / SGH-G400 / SGH-G600 / SGH-G608 / SGH-G800 / SGH-G808 / SGH-G810 / SGH-i200 / SGH-i320 / SGH-i325 / SGH-i400 / SGH-i450 / SGH-i458 / SGH-i458P / SGH-i520 / SGH-i550 / SGH-i560 / SGH-i568 / SGH-i600 / SGH-i607 / SGH-i608 / SGH-i610 / SGH-i616 / SGH-i617 / SGH-i620 / SGH-i640 / SGH-i640v / SGH-i710 / SGH-i7110 / SGH-i718 / SGH-i740 / SGH-i760 / SGH-i780 / SGH-i850 / SGH-i8510 / SGH-i900 / SGH-i907 / SGH-J150 / SGH-J200 / SGH-J208 / SGH-J210 / SGH-J400 / SGH-J600 / SGH-J608 / SGH-J610 / SGH-J630 / SGH-J700 / SGH-J708 / SGH-J750 / SGH-J758 / SGH-J800 / SGH-L170 / SGH-L310 / SGH-L320 / SGH-L400 / SGH-L600 / SGH-L700 / SGH-L760 / SGH-L768 / SGH-L770 / SGH-L810v / SGH-L870 / SGH-M110 / SGH-M130 / SGH-M140 / SGH-M150 / SGH-M200 / SGH-M300 / SGH-M305 / SGH-M310 / SGH-M3200 / SGH-M3510 / SGH-M520 / SGH-M600 / SGH-M610 / SGH-M618 / SGH-M620 / SGH-M7500 / SGH-M800 / SGH-M8800 / SGH-P180 / SGH-P220 / SGH-P300 / SGH-P308 / SGH-P310 / SGH-P520 / SGH-P720 / SGH-P850 / SGH-P858 / SGH-P910 / SGH-P920 / SGH-P930 / SGH-P940 / SGH-P960 / SGH-R200 / SGH-R500 / SGH-S3600 / SGH-S501i / SGH-S730i / SGH-S7330 / SGH-S7330 GT / SGH-T109 / SGH-T219 / SGH-T229 / SGH-T309 / SGH-T329 / SGH-T339 / SGH-T409 / SGH-T429 / SGH-T439 / SGH-T439 / SGH-T459 / SGH-T509 / SGH-T509s / SGH-T519 / SGH-T539 / SGH-T629 / SGH-T639 / SGH-T729 / SGH-T737 / SGH-T739 / SGH-T747 / SGH-T809 / SGH-T819 / SGH-T900 / SGH-T919 / SGH-U100 / SGH-U300 / SGH-U430 / SGH-U470 / SGH-U510 / SGH-U600 / SGH-U608 / SGH-U700 / SGH-U708 / SGH-U710 / SGH-U800 / SGH-U908 / SGH-V804 / SGH-X820 / SGH-X828 / SGH-X830 / SGH-X838 / SGH-Z140 / SGH-Z150 / SGH-Z170 / SGH-Z230 / SGH-Z240 / SGH-Z300 / SGH-Z360 / SGH-Z368 / SGH-Z370 / SGH-Z400 / SGH-Z400v / SGH-Z510 / SGH-Z510i / SGH-Z518 / SGH-Z540 / SGH-Z540v / SGH-Z548 / SGH-Z560 / SGH-Z620 / SGH-Z630 / SGH-Z650i / SGH-Z710 / SGH-Z720 / SGH-Z728 / SGH-ZV40 / Slash / SLM / Solid / Soul / Soul B / Spex / SPH-A303 / SPH-A420 / SPH-A460 / SPH-A500 / SPH-A503 / SPH-A513 / SPH-A523 / SPH-A560 / SPH-A600 / SPH-A620 / SPH-A640 / SPH-A660 / SPH-A680 / SPH-A700 / SPH-A740 / SPH-A760 / SPH-A800 / SPH-A820 / SPH-A840 / SPH-A880 / SPH-A920 / SPH-A940 / SPH-i325 / SPH-M200 / SPH-M210 / SPH-M220 / SPH-M300 / SPH-M305 / SPH-M310 / SPH-M320 / SPH-M510 / SPH-M520 / SPH-M540 / SPH-M610 / SPH-M620 / SPH-M630 / SPH-M800 / SPH-N240 / SPH-N270 / SPH-N400 / SPH-U510 / SPH-W6300 / SPH-Z400 / Steel / Stripe / Sync / T*Omnia / T10 / T9 / T929 / Tbird / The Button / The Ultra Edition 11.8 / The Ultra Edition 12.1 / The Ultra Edition 12.9 / The Ultra Edition 13.8 / The Ultra Edition 5.9 / The Ultra Edition 6.9 / The Ultra Edition 9.9 / The Ultra Edition II 10.9 / The Ultra Messaging / The Ultra Music Edition / The Wafer / Tocco / TOUCHWiZ / Trace / U3 / Ultra Edition III 12.9 / Upstage / VGA-1000 / VI-660 / VM-A680 / WEP150 / WEP170 / WEP180 / WEP185 / WEP200 / WEP210 / WEP301 / WEP350 / WEP410 / WEP500 / WEP700

Sandisk

[Sansa / Sansa Clip / Sansa Shaker](#)

Sanyo

[Katana Eclipse / Katana Eclipse X / Katana LX / MM-7500 / MVP EV-DO / PM-8200 / PRO-200 / PRO-700 / RL-2000 / RL-4930 / RL-7300 / S1 / SCP-4920 / SCP-4930 / SCP-7050 / SCP-7200 / VM-5500](#)

Sharp

Sidekick

[LX / Slide](#)

Siemens

[SX-56](#)

SoftBank

[705SC / 706SC / 708SC / 709SC / 930SC](#)

Sony

[Walkman NW-E405 / Walkman NW-E407 / Walkman NW-E507 / Walkman NW-S205F](#)

Sony Ericsson

[C702 / C702a / C702c / C901 / C902 / C902c / C903 / C905 / D750 / D750i / F305 / G502 / G700 / G700 Business Edition / G700c / G705 / G900 / HBH-20 / HBH-200 / HBH-300 / HBH-35 / HBH-60 / HBH-600 / HBH-602 / HBH-608 / HBH-610 / HBH-610a / HBH-65 / HBH-660 / HBH-662 / HBH-DS200 / HBH-DS220 / HBH-DS970 / HBH-DS980 / HBH-GV435 / HBH-GV435a / HBH-GV835 / HBH-IV835 / HBH-IV840 / HBH-PV700 / HBH-PV702 / HBH-PV703 / HBH-PV705 / HBH-PV708 / HBH-PV710 / HBH-PV712 / HBH-PV712 Style Edition / HBH-PV715 / HBH-PV720 / HBH-PV740 / HBH-PV770 / HBV-100 / HCB-100E / HCB-105 / HCB-120 / Hikaru / Idou / J100 / J100a / J100c / J100i / J110a / J110c / J110i / J120c / J120i / J132 / J220 / J220a / J220c / J220i / J221 / J230 / J230a / J230c / J230i / K200a / K200c / K200i / K205a / K205i / K220c / K220i / K310 / K310a / K310c / K310i / K320i / K330 / K510 / K510a / K510c / K510i / K530c / K530i / K550 / K550c / K550i / K550im / K610 / K610c / K610i / K610im / K618 / K618i / K630i / K660 / K660i / K750 / K750c / K750i / K758c / K770i / K790 / K790a / K790c / K790i / K800 / K800c / K800i / K810i / K818c / K850 / K850i / K858c / M600i / M608 / M608c / MBR-100 / MBW-100 / P1c / P1i / P990c / P990i / R300 / R306 / R306a / R306c / S302 / S500 / S500c / S500i / S600i / T250a / T250i / T258c / T270i / T280a / T303 / T303c / T650i / T658c / T700 / TM506 / V630i / V640i / W200 / W200a / W200c / W200i / W300 / W300c / W300i / W302 / W350a / W350c / W350i / W380a / W380c / W380i / W395 / W508 / W530a / W550c / W550i / W580c / W580i / W580im / W595 / W595a / W600 / W600c / W600i / W610 / W610c / W610i / W618c / W660 / W660i / W700 / W700c / W700i / W705 / W710 / W710c / W710i / W712 / W715 / W760c / W760i / W800 / W800c / W800i / W810 / W810c / W810i / W830 / W830c / W830i / W850 / W850i / W850im / W880 / W880i / W888c / W890i / W900 / W900c / W900i / W902 / W908c / W910 / W910i / W950 / W950c / W950i / W958c / W960 / W960i / W980 / W980i / W995 / Z250a / Z250i / Z300a / Z300c / Z300i / Z310a / Z310i / Z320a / Z320i / Z520a / Z520c / Z520i / Z525 / Z525a / Z525i / Z530 / Z530c / Z530i / Z550 / Z550a / Z550c / Z550i / Z555i / Z558 / Z558c / Z558i / Z610 / Z610i / Z710 / Z710c / Z710i / Z712 / Z750 / Z750a / Z750i / Z770i / Z780a / Z780i / Z850a](#)

TomTom

[Go 520 / Go 720 / Go 730 / Go 920 / Go 920T / Go 930 / One / One 3rd Edition / One Europe / One Regional / One XL / One XL Europe / One XL Regional / One XL S](#)

Toshiba

[CDM9950SP / MEU202-BK / MEU202-SL / Portege G500 / Portege G900 / VM4050](#)

UBIQuiO

[501 / 503G](#)

Voice Star

[VS600](#)

VuGo

[VuGo](#)

Wi-Gear

[iMuffs](#)

ZTE