MASH

LAX SERIES / HEAD BOARD SHELF
MOUNTING TEMPLATE

HOLE

HOLE

MOUNTING INSTRUCTIONS

NOTE: Wall mounting hardware provided for use only if your walls are hollow wall construction. For mounting on any other application, please consult your nearest hardware store.

Find a location for your new Shelf to be wall mounted.

Tape given template onto wall of your choice, in the exact desired location making sure template is completely flat.

Drill (4) holes using a 1/2" drill bit into template holes.

Remove template.

Insert (4) toggles, as per diagram instructions (included).

After toggles are installed align holes in wall with holes in back of cabinet. Insert 1/4-20 bolts tighten by hand, do not over tighten.

Once cabinet is securely attached with all 4 bolts, slide aluminum covers on from the side.

Max weight load not to exceed 90LBS.

Drill a 1/2" hole. Hold metal channel flat alongside plastic straps and slide channel through hole.

Hold ends of straps between thumb and forefinger and pull toward you until channel is flush against wall. Slide plastic cap along straps with other hand until flange of cap is flush with wall.

HOLE

HOLE

Snap straps at wall by pushing side to side, snapping off straps level with flange of cap.

Place item over flange. Insert bolt through item and tighten until flush against item, then stop.

For	DRILL SIZE	BOLT IN BAG
3/8" - 3 3/8" THICK WALLS OR CEILINGS	1/2"	1/4 -20 x 2-1/2"

TOGGLER

SNAPTOGGLE 100

Patented under one or more of U.S. Patent Nos. 5,772,377; 6,102,626; 6,106,207; 6,109,854; 6,234,724; 6,241,454; Other patents pending. Toggler, Snaptoggler, Snapcap, Snapstrap, Toggler Hardware, and Mounting Hardware Made Easy are trademarks of Toggler Hardware, Inc.
© 2000 MHI

HOLE

HOLE